



! DO NOT SHORT CIRCUIT THE LIPO BATTERY
 CHECK THE DC-DC BOOSTER IS SUITABLE FOR THE LIPO BATTERY INPUT VOLTAGE
 BE CAREFUL AND USE LIPO BATTERIES WITH CARE

OPTIONAL - LINK IF NO BATTERY MONITOR
 OPTIONAL - BATTERY VOLTAGE MONITOR
 DO NOT USE BOTH METHODS

Title OTTO - QUAD		BASIC CONNECTION	
Author			
File \Users\E330 Edge\Do ... tCad2 OTTO QUAD.dsn			Document
Revision 1.0		Date FEB 19	
			Sheets 1 of 1